



VELUX®

VELUX flat roof window

Installation in roofing felt

Installing VELUX flat roof windows in roofing felt is quick thanks to the felt's flexibility. Roofing felt easily forms to the window, and VELUX flat roof windows even have an upstand for the felt to adhere to.

This handy guide takes you through the installation process step by step. Please read the complete installation instructions before installing your VELUX flat roof window in roofing felt.



1. Remove the existing roof window from the roof
2. Prepare the roof for the new installation
3. Position the new VELUX flat roof window over the existing hole
4. Predrill the holes in the window according to the installation instructions
5. Screw the window tightly into place as shown in the installation instructions
6. Apply roof primer to the sides of the window
7. Apply roof primer to the roof
8. Burn the first layer of roofing felt to the roof and window



- 9.** Assemble the corner joints in the roofing felt according to local regulations
- 10.** Burn the second layer of roofing felt to the roof and window
- 11.** Attach the roofing felt with VELUX metal profiles (ZZZ 210, optional)
- 12.** Install the rain sensor (only for model CVP)
- 13.** Mount the dome on top of the window

Bringing light to life™

VELUX®

VELUX
flat roof windows